

FIG 1






FIG 2






FIG 5




FIG 6

When power is applied to the generator, the battery charger, cab heater, air conditioner, and other electrical loads are connected to the generator through the switches and fuses.





FIG 7

THIS DRAWING IS THE PROPERTY OF THE U.S. AIR FORCE. IT IS TO BE KEPT SECRET AND NOT DISCLOSED TO ANY OTHER PERSON OR ORGANIZATION WITHOUT THE WRITTEN PERMISSION OF THE U.S. AIR FORCE.



F16 8




FIG. 9